



Legato Assembly Guide

Flat Blade Post - Surface Mount - Flat arm - End & Mid Post

- 1. Plumbing Legato Post.** Before completing attachment of Legato post/posts to substrate - take all necessary steps to assure that the mounted post/posts are adjusted such that the post/posts are plumb to 1/16" at an extended height of 42". Spend the time required to plumb the post/posts to this tolerance to ensure correct alignment of all components.
- 2. Decorative Flange Cover.** Decorative flange cover is supplied already mounted to post (1).
- 3. Install Flat Arm Clips.** Take flat arm assembly parts (2), (3) & (4), slide assembly over post (1) locating holes pre-drilled in part (2) over corresponding threaded holes in post (1). Using countersunk head screws (5) fix flat arm assembly (2), (3) & (4) directly to post (1).
- 4. Install Glass Infill Panel.** Remove flat head fixing screw and circular metal disk, black circular gaskets and plastic tubular isolation grommet. Repeat process for all flat arm clips. Have someone hold the glass panel in place between the flat arm clips. Make sure a circular black gasket is located between the glass and inner circular flat arm clip pressure plate. Place tubular plastic grommet in hole within glass panel. Place second circular black gasket and the screw flat head fixing screw into threaded portion of flat arm assembly. Tighten flat head fixing to (10-15ft-lbf torque). Ensure glass panel is level.
- 5. Install Hand Rail.** Place handrail on top of saddle bracket/brackets and temporarily secure in place. Using pre-drilled holes in saddle bracket mark handrail. Drill handrail and secure to saddle bracket using a #10 sheet metal screw (Not included).

